





(2) Printed Graphic Fabric Banner (Optional)












STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Slide fabric banner on frame from top and zip up at bottom.




(1) Hardware



(2) Printed Graphic Fabric Banner (Optional)



STEP 01 Connect poles according to labelings.



STEP 02 Slide fabric banner on frame from left and zip up at right.







(1) Hardware



(2) Printed Graphic Fabric Banner (Optional)



STEP 01


Connect to make long poles according to labelings.








STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Install cross bars in position.










STEP 04 Slide fabric banner on frame from top and zip up at bottom.







Booth Set Assembly








(3) 90° C-Shaped Clip & 180° C-Shaped Clip



(2) Shelf & Bracket



(4) TV Mount & Screw






Interconnect display stands with C-shaped clips.











STEP 03

Screw TV mount onto display stand & support brackets onto TV's back with hex wrench, hang TV onto mount & screw.



STEP 04


Screw brackets onto display stand with hex wrench, insert shelves into slots.





STEP 05 Screw light clips at top of display stands, slide lights onto them and adjust their direction.







(1) Durable Plastic Hard Case, Aluminum Support Poles



(2) Printed Graphic Fabric Banner



STEP 01

Put hard case's top into fabric banner.






STEP 02

Insert support poles into hard case's top & bottom.







STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.



