

STEPS

(1) Hardware





(2) Printed Graphic Fabric Banner (Optional)





STEP 01

① Hold pop up frame in standing position.



Watch out pop up frame's scissor sections in case of getting pinched.

② Two people stand across from each other, hold pop up frame's "V" section, step back & lift up to expand it to roughly half overall width.



③ Unpack canopy top fabric banner & place it on top of pop up frame, align their corners together with velcro.

STEPS

STEP 02


Two people stand across from each other, hold pop up frame's leg, step back & lift up to expand it to overall width.



Make auto-slider to top & lock in position with a sound of "Click".

STEP 03


Two people adjacently step on triangular foot & telescope up leg until they lock into lowest holes.



STEP 04

Repeat action on other two legs. There are 4 height options to choose from. Press down red button on leg joint & pull up leg until it locks into desired height's hole.

Disassembly: Reverse assembly instructions. Press down red button on leg joint & auto-slider to unlock pop up frame to fold up.



SPT-H-02V2